EU-202609

Warranty Statement and Maintenance Manual

Emkoo

Emzoom

GS7

Foreword

Dear Customer,

Thank you for choosing a GAC vehicle. We sincerely appreciate your trust and confidence in our brand. Our commitment is to deliver products and services of the highest quality, ensuring that every journey you take is safe, comfortable, and worry-free.

To maintain your vehicle in optimal condition throughout its service life, we kindly recommend that all scheduled maintenance be carried out by an authorized GAC repairer in accordance with the regular maintenance schedule provided in this manual. At our authorized service centers, your vehicle will be serviced by technicians who have received specialized GAC training and who adhere strictly to our official service standards and procedures.

This document is the official warranty and scheduled maintenance record for your vehicle.

Copyright for this document is reserved by GAC. GAC is responsible for the maintenance, interpretation, and clarification of the information contained herein. The information and technical data contained in this document are valid and effective as of the date it is provided to you. Any subsequent updates, revisions, or amendments issued by GAC shall prevail over the information contained in this document.

We wish you many safe and enjoyable journeys!

GAC Motor Europe B.V.

September, 2026

1	Vehicle Delivery	3
1.1	Pre-delivery inspection	3
1.2	Vehicle delivery	3
2	Warranty	4
2.1	Basic vehicle warranty	4
2.2	Paint warranty	5
2.3	Spare parts warranty	5
2.4	Warranty exclusions	6
3	Maintenance instructions	9
3.1	Regular maintenance	9
3.2	Supplementary maintenance under harsh driving conditions	16
3.3	Regular maintenance record	18

1 Vehicle Delivery

1.1 Pre-delivery inspection

The vehicle identified in the Warranty Certificate attached to this manual has undergone a comprehensive pre-delivery inspection in accordance with GAC standards. This inspection ensures that the vehicle meets our quality requirements and is fully prepared for delivery to you.

1.2 Vehicle delivery

Prior to delivery, your vehicle will be thoroughly inspected by an authorized GAC repairer to ensure it meets our quality and safety standards.

If you have any specific requests regarding vehicle settings or adjustments, please inform your authorized GAC repairer before delivery so that the necessary arrangements can be made.

2 Warranty

2.1 Basic vehicle warranty

GAC Motor Europe B.V., a company incorporated under the laws of the Netherlands and having its registered office in Amsterdam (hereinafter referred to as “GAC”), acts as the warrantor of GAC-branded vehicles and products.

The authorized representative of the Manufacturer designated to act on behalf of the warrantor within the territory of Poland is Jameel Motors Poland GAAC Sp. z o.o. with its registered office at Al. Ujazdowskie 41, 00-540 Warsaw, Poland, entered in the Register of Entrepreneurs of the National Court Register maintained by the District Court for the Capital City of Warsaw, 12th Commercial Division of the National Court Register, under KRS No. 0001109987, Tax Identification Number (NIP) 7011208860, and REGON 528855589.

The warranty period shall commence on the vehicle delivery date indicated on the original sales invoice. If the date specified on the invoice differs from the actual vehicle delivery date, the warranty period shall begin on the date the vehicle is physically delivered to the Customer.

Warranty coverage	Warranty Period (whichever comes first)
Basic vehicle warranty	5 years / 150 000 km
Power battery	5 years / 150 000 km, SOH 70%
Drive units	5 years / 150 000 km

2.2 Paint warranty

Warranty coverage	Warranty Period
Anti-Corrosion	10 years / unlimited milage
Paint	2 years / unlimited milage

Note：The Anti-Corrosion Warranty covers corrosion caused by defects in materials, manufacturing, or anti-corrosion treatment that results in perforation or affects vehicle function.

Surface rust, minor corrosion, and corrosion caused by external damage, environmental conditions, improper maintenance, repairs, modifications, or non-genuine parts are not covered.

2.3 Spare parts warranty

Spare parts	Warranty period (whichever comes first)
Spare parts	2 years / unlimited mileage from the date of purchasing invoice.
Power battery and drive units	4 years / 80 000 km

2.4 Warranty exclusions

The Vehicle Warranty does not cover any vehicle damage or malfunction directly or indirectly caused by normal wear, misuse, accident, improper maintenance, transport, including, but not limited to, any of the following:

1. Normal wear or deterioration, for example, seat depressions, wrinkling, abrasions or other deformations, and similar items.
2. Normal wear and tear of consumable parts, including but not limited to tires, brake system, wiper blades, and the 12V battery.
3. Failure to properly maintain the vehicle in accordance with the instructions provided in the owner's manual, including failure to carry out required maintenance, cleaning, inspection, appearance care, wheel alignment or balancing, or to promptly remove mud, dirt, salt, or other contaminants from the vehicle surface. Corrosion resulting from improper maintenance or cleaning is not covered.
4. Damage resulting from improper recovery, winching or towing the vehicle.
5. Force majeure, including, but not limited to, fire, explosion, earthquake, windstorm, flood, or deep water.
6. Driving over damaged or hazardous roads, including but not limited to driving off-road or participation in races, where such use results in external damage, corrosion, or other damage to the vehicle.
7. Overloading the vehicle.
8. Using the vehicle as a stationary power source in a manner not described in the owner's manual.
9. Harsh environmental conditions, including but not limited to road de-icing salt, seawater, chemicals, industrial pollutants, acid rain, animal or insect droppings, tree sap, or other corrosive substances.

10. External damage, including physical damage caused by stone chips, scratches, abrasions, dents, impact from road debris, tools, or third-party repairs, and any corrosion resulting from such external damage, including corrosion caused by damage that penetrates the paintwork from the outside in.

11. Accident or collision damage, including any corrosion or paint defect resulting from collision, accident repair, or structural modification.

12. Unauthorized repairs, modifications or alterations, including non-approved welding, drilling, sealing, painting, or other repair work, and any corrosion, paint deterioration, failure, or damage resulting from such work.

13. Water intrusion or poor drainage due to damage, including corrosion caused by blocked drain holes, improper drainage, water ingress due to accident, or unauthorized body modification.

14. Defects or damage caused by non-genuine spare parts or materials, including corrosion resulting from the use of non-genuine parts, materials, or improper repair materials.

15. General appearance and normal noises and vibrations, including minor discoloration, fading, dulling, normal surface oxidation, or minor surface corrosion that does not result in perforation or affect the normal function or performance of the vehicle.

16. Corrosion of components that are not part of the vehicle body structure, including exhaust pipes, bolts, nuts, fasteners, and other components subject to normal surface oxidation or corrosion, is not covered by the Anti-Corrosion Warranty.

17. Windshield or window glass broken, scratched, or cracked, where the damage is not caused by a defect in GAC-manufactured or supplied materials.

18. Components or equipment which are not part of the vehicle at the point of manufacturing.
19. Unauthorized odometer changes.
20. Failure to complete all marketing quality improvement measures as stipulated by GAC or the manufacturer.
21. Other failures, damage, or quality issues not attributable to defects in GAC's manufacturing, materials, design, or production processes.

Exercising rights under this warranty shall not affect or limit the Customer's statutory rights against the seller under applicable consumer protection laws.

The warrantor shall review any warranty claim without undue delay and, in any event, no later than 14 days from the date the vehicle is delivered to an authorized GAC service center. The warrantor shall fulfill its warranty obligations within 30 days of receiving the vehicle or the warranted item. In exceptional circumstances where compliance with the above timeframe is not reasonably possible, the period for performing the warranty service may be extended. In such cases, the Customer shall be promptly informed of the reasons for the delay and provided with a revised estimated completion date.

This warranty shall automatically transfer to any subsequent owner of the GAC vehicle. The warrantor reserves the right to request any person claiming warranty coverage following such a transfer to provide reasonable evidence confirming their current ownership of the vehicle.

3 Maintenance instructions

3.1 Regular maintenance

If necessary, follow the steps of addition, cleaning, washing, adjustment, lubrication, repair or replacement after inspection.

Maintenance items	Maintenance Interval (whichever comes first)
★ Change the engine oil and drain bolt washer.* * S7 (T68-G) only	first maintenance (5 000Km / 6 months), and every 15 000 Km / 12months
★Replace the engine oil filter.	
★ Replace the spark plug.	every 60 000 km.
★ Replace the spark plug* * GS4 MAX(T58-G1) 2.0TG engine 4WD model only.	every 45 000 km
Inspect auxiliary belt (if equipped.)	every 15 000 km / 12 months and replace if necessary
★Replace the V-ribbed belt.* *GS4 MAX(T58-G1) 2.0TG engine 4WD model only.	every 60 000 km
★ Replace the canister filter.	every 60 000 km / 48 months
Check and clean the air cleaner element.	first maintenance (5 000 km / 6 months)
★ Clean the cover of air cleaner and replace the air cleaner element.	every 15 000 km / 12 months
Check the cooling system for leakage and add the coolant when necessary.	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months

Maintenance items	Maintenance Interval (whichever comes first)
★ Change the engine coolant.	every 45 000km / 36 months
★ Change the coolant of HV battery (if equipped).	every 45 000km / 36 months
★ Replace the coolant of the intercooler system (if equipped).	every 45 000km / 36 months
★ Change coolant of electromechanical coupling system (if equipped).	every 45 000km / 36 months
★ Replace the electromechanical coupling transmission pressure filter element (if equipped).	first maintenance (5 000 km / 6months) and every 75 000 km / 60 months
★ Change electromechanical coupling transmission oil (if equipped).	first maintenance (5 000 km / 6months) and every 75 000 km / 60 months
★Replace the transmission fluid (7WDCT).	60 000 km / 48 months
★ Replace the press filter element (7WDCT).	first maintenance (5 000 km / 6months) and every 60 000 km / 48 months
★Replace the rear drive motor lubricating oil and drain out sealing gasket.* *S7(T68-G) only	every 30 000 km / 24 months
★ Change the brake fluid.	every 30 000 km / 24 months
Check body and underbody corrosion protection (repair if necessary).	every 30 000 km / 24 months
Check the exhaust (only for leakage; the exhaust compositions are to be inspected during the annual inspection).	every 15 000 km / 12months

Maintenance items	Maintenance Interval (whichever comes first)
Check the parking brake and the brake pedal (check the function and free travel of the pedal and parking brake).	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months
Check the brake disc and brake lining (check their thickness and wear pattern and replace them when necessary).	first maintenance (5 000 km / 6 months) then 15000 km / 12 months
Check the wheel fixing bolt (check and tighten the bolt to the specified torque).	first maintenance (5 000 km / 6 months) and every 15000 km / 12 months
Check the wear pattern of the tire/ hub (including the spare tire), carry out tire rotation and correct the tire pressure when necessary.	first maintenance (5 000 km / 6 months) and every 15000 km / 12 months
Check the chassis bolts (check and tighten the bolts to the specified torque).	first maintenance (5 000 km / 6 months) and every 15000 km / 12 months
Check the brake system (check the brake fluid lines for leakage; check the brake fluid level and add the brake fluid when necessary).	first maintenance (5 000 km / 6 months) and every 15000 km / 12 months
Check the steering tie rod (check the clearance and check whether the connection is firm).	first maintenance (5 000 km / 6 months) and every 15000 km / 12 months

Maintenance items	Maintenance Interval (whichever comes first)
Check the underbody (check the fuel pipe, brake fluid pipe and underbody protective layer for damage, and the exhaust pipe for leakage and looseness).	first maintenance (5 000 km / 6 months) and every 15000 km / 12 months
★ Replace the fuel hose.	every 96 months (or when any crack is found)
★ Replace the fuel filter.* *S7(T68-G) only	every 200 000 km
Check the suspension ball joint and dust cover (check for loose ball joint or leaky dust cover).	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months
Check the suspension assembly (check that the bush is free from aging and breakage, the connecting bolt and nut are tightened to specified torque and the linkage is free from deformation and cracks).	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months
Check the wiper/washer (add the washer fluid and check the function of wiper/washer, adjust the nozzle when necessary).	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months
Check whether there are leaves or other debris on the surface of the wiper cover.	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months
Clean the drain holes of the sunroof drip channel (four).	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months

Maintenance items	Maintenance Interval (whichever comes first)
Check the door check, dowel pin, door lock, engine hood/ trunk lid hinge and latch (check their functions and clean the dust on the door check and lubricate the check).	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months
Grease the power liftgate drive rod/ balance rod/ balance rod ball socket (without removing two rods); required grease: lithium soap base synthetic hydrocarbon with high viscosity and operating temperature of -30°C~120°C.	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months
Check the rear seat backrest lock (check function, clean dust and lubricate).	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months
Check the interior and exterior lamps and electrical consumers of the vehicle body.	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months
Read OBD in-use monitoring data.	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months
Self-diagnosis (check the fault message with the professional diagnostic scan tool).	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months
Check the battery (check the battery condition with the special tool, check if the connections to the positive and negative terminals of battery are firm and check the battery voltage).	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months

Maintenance items	Maintenance Interval (whichever comes first)
Check the headlamp (check the lamplight and adjust it when necessary).	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months
Check the A/C filter element.	first maintenance (5 000 km / 6 months)
★ Replace the A/C filter element.	every 15 000 km / 12 months
Test run (performance inspection).	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months
Visually check the following items	
Dust cover of drive shaft (check for oil leakage or damage).	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months
Check whether the refrigerant connector is loose and whether the refrigerant pressure is sufficient and add refrigerant if necessary.	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months
Check the through-hole rubber plug of the exhaust pipe for looseness or water leakage.	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months
Check whether the high-voltage harness and low-voltage harness of the power battery are connected firmly and read DTCs with the diagnostic scan tool.	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months

Maintenance items	Maintenance Interval (whichever comes first)
Check whether the electromechanical coupling transmission involves oil leakage, liquid leakage, scratch or damage; and whether the bolts for connecting with the engine and the rear mounting bracket involve looseness or torque attenuation.	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months
Check whether the high/low-voltage harnesses of the electromechanical coupling transmission are firmly connected without interference with surrounding parts or dynamic interference wear; and whether the fixing bracket is loose, etc.	first maintenance (5 000 km / 6 months) and every 15 000 km / 12 months
★: Check the amount of engine oil, coolant and brake fluid carefully before each time of driving. *1: The spark plug shall be replaced frequently if the gasoline you use contains impurities. Replace the spark plug immediately if unstable engine idling is found. *2: The fuel filter shall be replaced frequently if the gasoline you use contains impurities. Replace the fuel filter immediately if the filter is clogged by impurities. *3: It is a consumable part. It is recommended that users check it regularly and go to the GAC service center for repair when abnormalities are found.	

3.2 Supplementary maintenance under harsh driving conditions

Maintenance intervals are based on normal driving conditions and may require additional maintenance items or reduced intervals if the vehicle is frequently used in harsh conditions, please contact the GAC authorized repairer. The following conditions are considered bad driving conditions:

1. Drive in a high dust environment, such as desert, construction site, etc.
2. Drive in severe cold (below -20°C) or high temperature (above 40°C).
3. Drive in a humid environment or wade frequently.
4. Drive on the road surface of salt or corrosive material.
5. Engage in commercial operational activities or often be used for high-load use.
6. Engage in off-road driving, racing or competitive activities.

Maintenance items	Harsh condition	Maintenance Interval
Check wheel fixing bolts	1, 2, 3, 4, 5, 6	Every 10,000 km or 6 months
Check chassis bolts (check and tighten bolts to specified torque)	1, 2, 3, 4, 5, 6	Every 10,000 km or 6 months
Check steering level (check clearance, check that connections are secure)	1, 2, 3, 4, 5, 6	Every 10,000 km or 6 months
Check suspension ball connector and dust cover (check ball connector for loose or dust cover for water leaking)	1, 2, 3, 4, 5, 6	Every 10,000 km or 6 months
Check the suspension assembly (check that the bushing is free from aging and breakage, the connecting bolts and nuts are tightened to the specified torque, and the connecting rod is free from deformation and crack)	1, 2, 3, 4, 5, 6	Every 10,000 km or 6 months
Replace air conditioning element	1, 2	Every 10, 000 km

3.3 Regular maintenance record

All vehicle service operations, including scheduled maintenance inspections, adjustments, repairs, and warranty repairs, are recorded in the information systems of authorized GAC service centers and in the central systems of GAC Europe.

Compliance with the maintenance schedule specified in the Periodic Maintenance Schedule is a mandatory condition for maintaining warranty coverage and preserving the rights granted under the manufacturer's warranty.

Your satisfaction is our highest priority. Should you have any questions, concerns, or require assistance, please do not hesitate to contact us through an authorized GAC service center or directly through GAC Customer Support. We will be pleased to assist you.